

*air*Cam

Security Camera  
Camera Configuration Interface

USER GUIDE

## Table of Contents

---

<b>Chapter 1: Product Overview</b> .....	1
Package Contents .....	1
Installation Requirements .....	1
System Requirements .....	1
Hardware Overview .....	1
<b>Chapter 2: Installation</b> .....	2
Outdoor Installation .....	2
Indoor Installation .....	3
Connecting the Power .....	4
<b>Chapter 3: Using the Camera Configuration Interface</b> .....	5
Adjusting the Camera View .....	5
Navigation .....	5
Tools .....	6
<b>Chapter 4: Main Tab</b> .....	7
Status .....	7
Monitor .....	8
<b>Chapter 5: Video Tab</b> .....	10
Video Settings .....	10
<b>Chapter 6: Network Tab</b> .....	11
Network Settings .....	11
VLAN Network Settings .....	12
Firewall Settings .....	12
Static Routes .....	13
Advanced Ethernet Settings .....	13
<b>Chapter 7: Services Tab</b> .....	14
Ping Watchdog .....	14
SNMP Agent .....	15
Web Server .....	15
SSH Server .....	15
Telnet Server .....	15
NTP Client .....	15
Dynamic DNS .....	16
System Log .....	16

<b>Chapter 8: System Tab</b> .....	17
Device .....	17
Date Settings.....	17
System Accounts .....	18
Configuration Management .....	18
Device Maintenance.....	18
<b>Appendix A: Specifications</b> .....	20
<b>Appendix B: Safety Notices</b> .....	21
Electrical Safety Information .....	21
<b>Appendix C: Warranty</b> .....	22
General Warranty.....	22
<b>Appendix D: Compliance Information</b> .....	23
Installer Compliance Responsibility .....	23
FCC .....	23
Industry Canada.....	23
Class B Korea .....	23
CE Marking.....	23
RoHS/WEEE Compliance Statement .....	24
<b>Appendix E: Declaration of Conformity</b> .....	25
<b>Appendix F: Contact Information</b> .....	26
Ubiquiti Networks Support .....	26

# Chapter 1: Product Overview

Thank you for purchasing the airCam™, by Ubiquiti Networks. The airCam is a professional-grade H.264 IP indoor/outdoor camera that features 1MP/HDTV 720p/30 FPS capabilities and works in low-light and night-viewing environments.

This User Guide is designed to provide instructions about installation of the airCam and to provide details about how to set up and use the airCam configuration interface.

The airCam includes the airVision™ software. airVision is a comprehensive camera management software solution from Ubiquiti Networks, Inc. that is designed to work with Ubiquiti's airCam product line. The software interface design is based on the popular and easy-to-use UniFi™ software interface.


For instructions on using the airVision software, refer to the documentation included on the CD-ROM.

The airCam includes the necessary hardware for properly mounting the unit to a wall both indoors and outdoors. The airCam supports Passive PoE which works with the included PoE adapter.

The hardware installation process is different for indoor and outdoor installations. After familiarizing yourself with the airCam in the *Hardware Overview* section, please proceed to the appropriate installation section:

- **“Outdoor Installation” on page 2**
- **“Indoor Installation” on page 3**

## Package Contents



## Installation Requirements



- Pencil
- Drill and 6mm drill bits

## System Requirements


- Microsoft Windows XP, Windows Vista, Windows 7, or Mac OS X
- Java Runtime Environment 1.6 (or above)
- Web Browser: Mozilla Firefox, Google Chrome, or Microsoft Internet Explorer 8 (or above)

## Hardware Overview


### Front



### Back



### LEDs




- ⏻ **Power** The Power LED will light steady orange when the airCam is connected to a power source.
- ↔ **Ethernet** The Ethernet LED will light steady green when an active Ethernet connection is made and flash when there is activity.

# Chapter 2: Installation

The installation process is different depending on if you are mounting the camera outdoors or indoors. Follow the instructions for the installation that you are performing.


## Outdoor Installation

**!** **Important:** The ideal outdoor location for mounting the airCam would be under an overhang/eave that shelters the camera. If the airCam is located in a completely open outdoor environment without an overhang/eave, do not install camera with a down tilt of more than 45 degrees.




1. Press down on the release to remove the *Ethernet Door*.


**!** **Important:** Do not remove the plug.




2. Connect the Ethernet cable to the Ethernet port.




3. Insert the seal into the bottom of the camera and wrap the seal around the Ethernet cable. Reconnect the *Ethernet Door* to the airCam leaving the Ethernet cable fed through the seal at the bottom of the camera.



4. Insert the *Mounting Bracket* into the airCam until a click is heard to confirm a secure installation.




- There are three recessed areas for the Ethernet cable on the *Mounting Bracket Base*. Thread the Ethernet cable through two of the recessed areas and out the one that will be nearest to your power source.




- Important:** If the power source is above the camera extend the cable 70-80 mm below the camera body before routing up to the power source.

- Position the *Mounting Bracket* in the desired location and use a pencil to mark the holes on the wall.
- Use a 6 mm drill bit to drill the holes in the wall.
- Insert the 3 screw anchors into the wall.
- Secure the wall-mount bracket to the wall by inserting the self tapping screws into the anchors.




## Indoor Installation


- Remove the screw and knob that connect the *Mounting Bracket Base* to the camera attachment by turning the knob counter-clockwise.




- Insert an Ethernet cable through the *Mounting Bracket Base*.




- Reconnect the *Mounting Bracket Base* to the camera attachment by reconnecting the screw and knob. Turn the knob clockwise to lock the camera attachment back to the *Mounting Bracket Base*.




- Unscrew the *Plug* on the back of the airCam.




5. Connect the Ethernet cable to the Ethernet port.



6. Insert the *Mounting Bracket* into the airCam until a click is heard to confirm a secure installation.



7. Position the *Mounting Bracket* in the desired location and use a pencil to mark the holes on the wall.
8. Use a 6 mm drill bit to drill the holes in the wall.
9. Insert the 3 screw anchors into the wall.
10. Secure the wall-mount bracket to the wall by inserting the self tapping screws into the anchors.




**Note:** There are three recessed areas for the Ethernet cable on the *Mounting Bracket Base*. Place the Ethernet cable in the recessed area that will be nearest to your power source.

## Connecting the Power


1. Connect the other end of the Ethernet cable to the Ethernet port labeled **POE** on the *PoE Adapter*.



2. Connect an Ethernet cable from your LAN to the Ethernet port labeled **LAN** on the *PoE Adapter*.



3. Connect the power cord to the power port on the *PoE Adapter*. Connect the other end of the power cord to a power outlet. The Power LED should light up on the airCam.



Hardware installation is complete.

## Chapter 3: Using the Camera Configuration Interface

The airCam has a browser-based camera configuration interface for advanced camera management options.


To access the interface, perform the following steps:

1. Make sure that your host machine is connected to the same LAN as the airCam.
2. The airCam is set to DHCP by default. If you have a router or DHCP server providing addresses on your network, check your DHCP Client Table to obtain the address of the airCam.



**Note:** If you do not have a DHCP server, the airCam defaults to the IP address **192.168.1.20**.


3. Launch your Web browser and in the address field, type **http://** and then the IP address of the airCam, for example: **http://192.168.1.20**. Press enter (PC) or return (Mac).




4. The login screen will appear. Enter **ubnt** in the *Username* and *Password* fields and click **Login**.



5. The *Main* screen will appear and you should see a live stream of video from the airCam.



## Adjusting the Camera View



## Navigation

The airCam configuration interface contains five main tabs, each of which provides a web-based management page containing configurable parameters that affect a specific aspect of the airCam:

- **Main** The *Main* tab displays airCam status/statistical information and provides video and client monitoring links. For detailed information, refer to **“Main Tab” on page 7**
- **Video** The *Video* tab allows you to configure Video Settings including the Bit Rate, Quality, Frame Rate, and Refresh Frequency for the airCam. For detailed information, refer to **“Video Tab” on page 10**
- **Network** The *Network* tab covers the configuration of the Network Settings, VLAN Network Settings, Firewall Settings, Static Routes, TCP Explicit Congestion Notification and Advanced Ethernet Settings. For detailed information, refer to **“Network Tab” on page 11**
- **Services** The *Services* tab covers the configuration of system management services including Ping Watchdog, SNMP Agent, Web Server, SSH Server, Telnet Server, NTP Client, Dynamic DNS, and System Log. For detailed information, refer to **“Services Tab” on page 14**
- **System** The *System* tab contains controls for airCam Device Settings, Date Settings, System Accounts, Configuration Management and Device Maintenance. For detailed information, refer to **“System Tab” on page 17**

The airCam configuration interface also contains network utility tools including:


- **Ping**
- **Traceroute**



## Tools

### Ping

The *Ping* tool is used to check the preliminary link quality and packet latency estimation between two network devices using ICMP packets.



### Network Ping

**Select Destination IP** A remote system IP can be selected from the list which is generated automatically or can be specified manually.

**Packet Count** Enter the number of packets to send for the ping test.


**Packet Size** The size of the ICMP packets can be specified in this field.

**Start** The test is started using this button.

Packet loss statistics and latency time evaluation is provided after the test is completed.

### Traceroute


The *TraceRoute* tool allows tracing the hops from the device to a selected outgoing IP address. It should be used for finding the route taken by ICMP packets across the network to the Destination host.



**Destination Host** Enter the IP address of the destination host to which you want to find the route.

**Resolve IP Addresses** Resolution of the IP addresses (symbolically rather than numerically) can be enabled by selecting this option.

**Start** The test is started using this button.



## Chapter 4: Main Tab

The *Main* tab displays airCam status/statistical information and provides video and client monitoring links.

### Status

Status	
Device Name: UBNT	MAC Address: 00:27:22:60:00:12
Version: v1.0	LAN: 100Mbps-Full
Uptime: 04:12:29	
Date: 2011-08-23 18:10:24	

**Device Name** Displays the customizable name (ID) of the airCam. The Device Name can be modified on the *System* tab.

**Version** Displays the version of the airVision software installed.

**Uptime** This is the total time the airCam has been running since last power up (reboot) or software upgrade. The time is displayed in days, hours, minutes and seconds.


**Date** Displays the current system date and time. The date and time are displayed in YEAR-MONTH-DAY HOURS:MINUTES:SECONDS format. The system date and time is retrieved from the Internet using NTP (Network Time Protocol). The NTP Client is enabled by default on the *Services* tab. The device doesn't have an internal clock and the date and time may be inaccurate if the NTP Client is disabled or the device isn't connected to the Internet.

**MAC Address** Displays the Media Access Control (MAC) address of the airCam.

**LAN** Indicates the current status of the Ethernet port(s) connection. This can indicate that a cable is not plugged into a device and there is no active Ethernet connection. When cable is plugged in, negotiated data rate will be displayed; possible rates are 10Mbps or 100Mbps, or else Half duplex or Full duplex.


## Monitor

### Live View



Displays a live video view based on the settings configured on the *Video* tab.

### Camera Controls




Camera controls appear when the mouse pointer is placed over the Live View. Use the sliders to adjust *Brightness*, *Contrast*, *Saturation* and *Sharpness* settings. Click **Remember** to save camera settings.

### Connected Clients



Displays a list of clients that are currently viewing the video stream.

### Throughput



Throughput displays a visual representation of the current data traffic on the LAN in both graphical and numerical form. The chart scale and throughput dimension (Bps, Kbps, Mbps) changes dynamically according to the mean throughput value. The statistics are updated automatically.

**Refresh** Throughput statistics can be updated manually by clicking **Refresh**.

## DHCP Client

Shows the device's IP address, Netmask, Gateway, DNS Servers, DHCP Server, Domain, Total Lease Time and Remaining Lease Time. DHCP Client mode can be enabled on the *Network* tab.



**IP Address** Displays the airCam's IP address while operating in DHCP Client mode. It is assigned automatically by the DHCP server.

**Netmask** Displays the airCam's Netmask when operating in DHCP Client mode. It is assigned automatically by the DHCP server, which also assigns the IP address to the airCam.

**Gateway** Displays the airCam's gateway when operating in DHCP Client mode, which is assigned automatically by the DHCP server.

**Primary/Secondary DNS IP** Domain Name System (DNS) is an Internet "phone book" which translates domain names to IP addresses. These fields identify the server IP addresses that the airCam uses for translation.

**DHCP Server** Displays the IP address of the DHCP Server assigning the IP Address to the airCam.

**Domain** Displays the domain name.

**Total Lease Time** Shows the total time (validity) of the leased IP address assigned by the DHCP server.

**Remaining Lease Time** Displays the remaining time of the IP address leased by the DHCP server.

**Renew** DHCP Client Information can be renewed manually by clicking **Renew**.

**Release** DHCP Client Information can be released manually by clicking **Release**.

**Refresh** DHCP Client Information can be refreshed manually by clicking **Refresh**.

## ARP Table

Lists all the entries of the Address Resolution Protocol (ARP) table currently recorded on the airCam.

ARP is used to associate each IP address to the unique hardware Media Access Control (MAC) address of each device. It is important to have unique IP addresses for each MAC address or else there will be ambiguous routes in the network.

IP Address	MAC Address	Interface
192.168.25.1	3c:ea:4f:8a:81:29	LAN
192.168.25.123	10:9a:dd:ba:5a:7e	LAN

**IP Address** Displays the assigned IP address.

**MAC Address** Displays the Media Access Control (MAC) address of the device.

**Interface** Displays the interface that the device is on.

**Refresh** The information in the ARP Table window can be updated by clicking **Refresh**.

## Log

Lists all registered system events. By default, logging is not enabled. The Log can be enabled on the *Services* tab.


```

System Log
Dec 31 16:00:07 system: Start
Dec 31 16:00:07 syslogd started: BusyBox v1.18.4
Dec 31 16:00:07 init: starting pid 215, tty '/dev/null': '/sbin/udhcpd -f -l eth0 -s /etc/udhcpd/udhcpd'
Dec 31 16:00:07 init: starting pid 217, tty '/dev/null': '/bin/lighttpd -D -f /etc/lighttpd.conf'
Dec 31 16:00:08 init: starting pid 223, tty '/dev/null': '/bin/telnetd -P -p 23'
Dec 31 16:00:08 init: starting pid 228, tty '/dev/null': '/bin/dropbear -P -d /etc/perseitant/dropbear_
Dec 31 16:00:08 route: add default gw 192.168.1.1 failed [error: 1]
Dec 31 16:00:08 init: starting pid 235, tty '/dev/null': '/sbin/ntpclient -n -s -c 0 -l -h time.apple.c
Dec 31 16:00:08 init: starting pid 236, tty '/dev/null': '/bin/ubnt-streamer'
Dec 31 16:00:09 dropbear[228]: Not backgrounding
Dec 31 16:00:09 route: del default gw 192.168.1.1 failed [error: 1]
Dec 31 16:00:09 route: add default gw 192.168.1.1 failed [error: 1]

```

**Clear** All entries in the system log can be deleted by clicking **Delete**.


**Refresh** System Log content can be updated by clicking **Refresh**.



## Chapter 5: Video Tab

The *Video* tab allows you to configure basic *Video Settings* including the Bit Rate, Quality, Frame Rate and Refresh Frequency settings for the airCam.

### Video Settings




**Bit Rate, Kbit/s** This option allows the selection of the bit rate in kilobits per second. Options include *16, 64, 128, 256, 512, 1024, 1536, 2048, 4096*.

**Quality** This option allows the selection of the video quality. Options include *Poor, Medium, Standard, Good, Excellent* and *Determined by Bitrate*.

**Frame Rate, fps** This option allows the selection of the airCam's video frame rate in frames per second. Options include *1, 2, 3, 4, 5, 7, 10, 15, 20, 25, 30*.

**Refresh Frequency, Hz** This option allows the selection of the airCam's video refresh frequency in hertz. Options include *50 Hz* and *60 Hz*.

**Change** Click to save changes.



## Chapter 6: Network Tab

The *Network* tab covers the configuration of the Network Settings, VLAN Network Settings, Firewall Settings, Static Routes, TCP Explicit Congestion Notification and Advanced Ethernet Settings.

### Network Settings


**IP Address** The airCam can be set for static IP or can be set to obtain an IP address from the DHCP server it is connected to. One of the IP assignment modes must be selected:

- **DHCP** Choose this option to assign a dynamic IP address, Netmask, Gateway and DNS address by the local DHCP server.



- **DHCP Fallback IP** Enter the IP address for the airCam to use if a DHCP server is not found.
- **DHCP Fallback Netmask** Enter the Netmask for the airCam to use if a DHCP server is not found.

- **Static** Choose this option to assign the static IP settings for the airCam.



**Note:** IP Address and Netmask settings should be consistent with the address space of the network segment where the device resides.

- **IP Address** Enter the IP address of the airCam. This IP will be used for device management purposes.
- **Netmask** This is a value which when expanded into binary provides a mapping to define which portions of IP address groups can be classified as host devices and network devices. Netmask defines the address space of the network segment where the device resides. 255.255.255.0 (or /24) Netmask is commonly used on many C Class IP networks.

- **Gateway IP** Typically, this is the IP address of the host router which provides the point of connection to the Internet. This can be a DSL Modem, Cable Modem, or a WISP Gateway Router. The airCam will direct the packets of data to the gateway if the destination host is not within the local network.
- **Primary DNS IP** Enter the IP address of the Primary DNS (Domain Name System) server.
- **Secondary DNS IP** Enter the IP address of the Secondary DNS (Domain Name System) server. This entry is optional and only used if the primary DNS server is not responding.

**MTU** Enter the size (in bytes) of the largest protocol data unit the layer can pass on. When using slow links, large packets can cause some delays thereby increasing lag and latency. By default, the MTU is set to 1500 bytes.

**Auto IP Aliasing** Automatically generates an IP Address for the corresponding LAN interface if enabled. The generated IP address is a unique Class B IP address from the 169.254.X.Y range (Netmask 255.255.0.0) which is intended for use within the same network segment only. Auto IP always starts with 169.254.X.Y while X and Y are last 2 digits from the MAC address of the device (i.e. if the MAC is 00:15:6D:A3:04:FB, Generated unique Auto IP will be 169.254.4.251).

**IP Aliases** IP aliases for the internal and external network interface can be configured. IP Aliases can be specified using the *LAN IP Aliases* configuration window which is opened when you click **Configure**.

IP	Netmask	Comment	Enabled
1.			<input type="checkbox"/>
2.			<input type="checkbox"/>
3.			<input type="checkbox"/>
4.			<input type="checkbox"/>
5.			<input type="checkbox"/>
6.			<input type="checkbox"/>
7.			<input type="checkbox"/>
8.			<input type="checkbox"/>

Save Cancel

- **IP** The alternative IP address for the LAN interface, which can be used for the routing or device management purposes.
- **Netmask** The network address space identifier for the particular IP Alias.
- **Comments** Field used for a brief description of the purpose of the IP Alias.
- **Enabled** Enables or disables the particular IP Alias. All added IP Aliases are saved in the system configuration file, however only the enabled IP Aliases are active on the device.

Newly-added IP Aliases can be saved by click the **Save** button or discarded by clicking the **Cancel** button in the *LAN IP Aliases* configuration window.

## VLAN Network Settings

VLAN Network Settings

Enable VLAN:

VLAN ID: 221

VLAN Network: LAN

**Enable VLAN** Enable this this feature to allow the management of the device to only occur on a specific management VLAN.

**VLAN ID** The VLAN ID is a unique value assigned to each VLAN at a single device; every VLAN ID represents a different Virtual Network. VLAN ID range values between 2 and 4094 are allowed. Only one VLAN ID is allowed per device.

**VLAN Network** Defines which network interface will be assigned to the specified VLAN ID.

## Firewall Settings

Firewall functionality can be enabled by clicking **Enable Firewall**.

Firewall Settings

Enable Firewall:  Configure...

Firewall rules can be configured, enabled or disabled using the *Firewall* configuration window which opens when you click **Configure**.

Action	Interface	IP Type	Not Source IP/Mask	Not Src Port	Not Destination IP/Mask	Not Dest Port	Comment	On
1. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
2. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
3. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
4. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
5. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
6. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
7. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
8. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
9. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
10. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
11. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
12. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
13. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
14. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
15. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
16. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
17. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
18. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
19. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>
20. DROP	ANY	IP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>

Save Cancel

Firewall entries can be specified by using the following criteria:

**Action** Allows two specific firewall rules: *ACCEPT* or *DROP*. By enabling *ACCEPT* the packets can pass the firewall unmodified. When choosing *DROP*, the packets are denied passage through the firewall and no response is sent.

**Interface** The interface where filtering of the incoming/passing-through packets are processed.

**IP Type** Sets which particular L3 protocol type (IP, ICMP, TCP, UDP) should be filtered.

**Source IP/Mask** The source IP of the packet (specified within the packet header), usually it is the IP of the host system which sends the packets.

**Src Port** The source port of the TCP/UDP packet (specified within the packet header), usually it is the port of the host system application which sends the packets.

**Destination IP/Mask** The destination IP of the packet (specified within the packet header), usually it is the IP of the system which the packet is addressed to.

**Dst Port** The destination port of the TCP/UDP packet (specified within the packet header), usually it is the port of the host system application which the packet is addressed to.

**Comment** Field used to enter a brief description of the firewall entry.

**On** Enables or disables the effect of the particular firewall entry. All added firewall entries are saved in system configuration file, however only the enabled firewall entries will be active on the device.

**Not** Can be used for inverting the Source IP/mask, Source Port, Destination IP/mask and Destination Port filtering criteria (i.e. if not is enabled for the specified Destination Port value 443, the filtering criteria will be applied to all the packets sent to any Destination Port except the 443 which is commonly used by HTTPS).

Click **Save** to save your firewall entries or click **Cancel** to discard your changes.

## Static Routes

Static routing rules can be added manually to the System Routing Table, allowing the specification of target IP address(es) that may pass through a determined gateway.

Static Routes functionality can be enabled by clicking **Configure**.

Static Routes

Static Routes:

For each entry, specify a valid *Target Network IP*, *Netmask*, *Gateway IP*, enter a *Comment* (optional), and select the *ON* check box, in order to enable this rule.

	Target Network IP	Netmask	Gateway IP	Comment	On
1.					<input type="checkbox"/>
2.					<input type="checkbox"/>
3.					<input type="checkbox"/>
4.					<input type="checkbox"/>
5.					<input type="checkbox"/>
6.					<input type="checkbox"/>
7.					<input type="checkbox"/>
8.					<input type="checkbox"/>
9.					<input type="checkbox"/>
10.					<input type="checkbox"/>
11.					<input type="checkbox"/>
12.					<input type="checkbox"/>
13.					<input type="checkbox"/>
14.					<input type="checkbox"/>
15.					<input type="checkbox"/>
16.					<input type="checkbox"/>
17.					<input type="checkbox"/>
18.					<input type="checkbox"/>
19.					<input type="checkbox"/>
20.					<input type="checkbox"/>

Click **Save** to apply changes or **Cancel** to discard them.

Click **Change** to save the changes made in the *Network* tab.

## TCP Explicit Congestion Notification

Transmission Control Protocol (TCP) Explicit Congestion Notification (ECN) can be enabled by selected **TCP ECN**.

TCP Explicit Congestion Notification

TCP ECN:

When enabled, TCP ECN reduces the number of packets dropped by the TCP connection. By avoiding a retransmission, this results in reduced latency and jitter.



**Note:** ECN is an optional feature that must be supported and enabled on both endpoints. TCP ECN is disabled on the airCam by default.

## Advanced Ethernet Settings

Advanced Ethernet Settings

Enable Autonegotiation:  Enable LED:

Link Speed, Mbps:

Enable Full Duplex:


**Enable Autonegotiation** When enabled, the airCam will automatically negotiate transmission parameters with the counterpart, such as Link Speed and Duplex. In this process, the connected devices first share their capabilities as for these parameters and then choose the fastest transmission mode they both support. To specify these values manually, clear the *Enable Autonegotiation* check box and select the appropriate values below.

**Enable LED** Selection turns LED next to the internal Ethernet port on or off.

**Link Speed, Mbps** Selects the maximum transmission link speed. There are two options: 10Mbps or 100Mbps. If running extra long Ethernet cables, a link speed of 10Mbps could help to achieve better stability.

**Enable Full Duplex** Selects the duplex mode; if enabled, the device operates in Full Duplex (allowing bidirectional communication in both directions simultaneously). While disabled, the device operates in Half-Duplex mode (allowing bidirectional communication in both directions, but not simultaneously and only in one direction at a time).






## Chapter 7: Services Tab

The *Services* tab covers the configuration of system management services including Ping Watchdog, SNMP Agent, Web Server, SSH Server, Telnet Server, NTP Client, Dynamic DNS, and System Log.

### Ping Watchdog

Ping Watchdog sets the airCam to continuously ping a user defined IP address (it can be the Internet gateway for example). If it is unable to ping under the user defined constraints, the airCam will automatically reboot. This option creates a kind of “fail-proof” mechanism.

Ping Watchdog is dedicated for continuous monitoring of the particular connection to remote host using the Ping tool. The Ping works by sending ICMP “echo request” packets to the target host and listening for ICMP “echo response” replies. If the defined number of replies is not received, the tool reboots the airCam.



**Enable Ping Watchdog** Enables the Ping Watchdog tool.

- **IP Address To Ping** Specify the IP address of the target host which to be monitored by the Ping Watchdog tool.
- **Ping Interval** Specify time interval (in seconds) between the ICMP “echo requests” are sent by the Ping Watchdog Tool. The default value is 300 seconds.
- **Startup Delay** Specify initial time delay (in seconds) until the first ICMP echo requests are sent by the Ping Watchdog tool. The default value is 300 seconds.  
The value of Startup Delay should be at least 60 seconds as the network interface and wireless connection initialization takes a considerable amount of time if the airCam is rebooted.
- **Failure Count to Reboot** Specify the number of ICMP echo response replies. If the specified number of ICMP echo response packets is not received continuously, the Ping Watchdog tool will reboot the airCam. The default value is 3.

## SNMP Agent

Simple Network Monitor Protocol (SNMP) is used in network management systems to monitor network-attached devices for conditions that warrant administrative attention. The airCam contains an SNMP agent which allows it to communicate to SNMP management applications for network provisioning.

The SNMP Agent provides an interface for device monitoring using the Simple Network Management Protocol (an application layer protocol that facilitates the exchange of management information between network devices). SNMP Agent allows network administrators to monitor network performance, find and solve network problems. For the purpose of equipment identification, it is always a good idea to configure SNMP agents with contact and location information:

**Enable SNMP Agent** Select to enable the SNMP Agent.

- **SNMP Community** Specify the SNMP community string. It is required to authenticate access to MIB objects and functions as an embedded password. The airCam supports a Read-only community string that gives read access to authorized management stations to all the objects in the MIB except the community strings, but does not allow write access. The airCam supports SNMP v1. The default SNMP Community is *public*.
- **Contact** Specify the contact who that should be notified in case an emergency situation arises.
- **Location** Specify the physical location of the airCam.

## Web Server

The following Web Server parameters can be set:

**Use Secure Connection (HTTPS)** If checked Web server will use secure HTTPS mode. HTTPS mode is unchecked by default.

- **Secure Server Port** Defines the Web Server TCP/IP port *Use Secure Connection (HTTPS)* is enabled.

**Server Port** Web Server TCP/IP port setting while using HTTP mode.

**Session Timeout** Specifies the maximum timeout before the session expires. Once a session expires, you must login again using the username and password.

## SSH Server

The following SSH Server parameters can be set:

**Enable SSH Server** This option enables SSH access to the airCam.

- **Server Port** SSH service TCP/IP port setting.
- **Enable Password Authentication** When enabled, you must authenticate using Administrator credentials in order to grant SSH access to the airCam, otherwise an Authentication Key will be required.
- **Authorized Keys** Click Edit to import a public key file working to get SSH access to the airCam instead of using an admin password. Click **Browse** to locate and select the key file, then click **Import**. Click **Save** to save your changes or **Close** to discard your changes.

## Telnet Server

The following Telnet Server parameters can be set:

**Enable Telnet Server** This option activates the Telnet access to the airCam.

**Server Port** Telnet service TCP/IP port setting.

## NTP Client

The Network Time Protocol (NTP) is a protocol for synchronizing the clocks of computer systems over packet-switched, variable-latency data networks. It can be used to set the airCam system time. System Time is reported next to the every System Log entry while registering system events if the *Log* option is enabled.

**Enable NTP Client** Enables the airCam to obtain the system time from a time server on the Internet.

- **NTP Server** Specify the IP address or domain name of the NTP Server.

## Dynamic DNS

**Enable Dynamic DNS** Select this check box to enable Dynamic DNS service for the airCam. Dynamic DNS is a network service providing which allows real-time notification to the DNS Server of any changes occurring in the airCam's IP setting, there by allowing access to the airCam through a Domain Name even if the airCam's IP address has changed.

**Host Name** Defines the Dynamic DNS Host Name. A large list of Dynamic DNS services is available here.

**Username** Defines the Dynamic DNS Username.


**Password** Defines the Dynamic DNS password. Select **Show** to display the password.

## System Log

**Enable Log** This option enables the registration routine of the system log messages. By default it is disabled.

- **Enable Remote Log** Enables the syslog remote sending function while System log messages are sent to a remote server specified in the *Remote Log IP Address* and *Remote Log Port* fields.
  - **Remote Log IP Address** The host IP address where syslog messages should be sent. Remote host should be configured properly to receive syslog protocol messages.
  - **Remote Log Port** The TCP/IP port of the host syslog messages should be sent. *514* is the default port for the commonly used system message logging utilities.

Every logged message contains at least a System Time and a Host Name. Usually a particular service name which generates the system event is specified also within the message. Messages from different services have different context and different level of the details. Usually error, warning or informational system service messages are reported, however more detailed Debug level messages can be reported also. The more detailed system messages are reported, the greater volume of log messages will be generated.



## Chapter 8: System Tab

The *System* tab contains controls for airCam Device Settings, Date Settings, System Accounts, Configuration Management and Device Maintenance.

### Device

Device Name (Host name) is the system wide device identifier. It is reported by the SNMP Agent to authorized management stations. Device Name will be represented in popular Router Operating Systems registration screens and discovery tools.



**Device Name** Specifies the system identity.

**Interface Language** Allows you to select the language displayed in the management interface. *English* is the default language.

Additional language profiles may be uploaded.

Refer to our wiki page at the following URL:

[www.ubnt.com/wiki/How to import Language Profile](http://www.ubnt.com/wiki/How_to_import_Language_Profile)

### Date Settings



**Timezone** Specifies the timezone according to GMT (Greenwich Mean Time).

**Enable Startup Date** When enabled, you are able to modify the device's startup date.

- **Startup Date** Specifies the device's startup date. You can select a date by clicking the **Calendar** icon or typing it in manually. Type the date in the following format: 2 digit month/2 digit day/4 digit year. An example would be for May 20th, 2010 you would type **05/20/2010**

## System Accounts

In this section you can modify the administrator password to protect your device from unauthorized configuration. The default administrator's password should be changed on the very first system setup:

**Administrator Username** Specifies the name of the system user.

**Key button** Press this button in order to change the administrator password.

- **Current Password** Enter the current password associated with the administrator account. It is required to change the *Password* or *Administrator Username*.
- **New Password** Enter the new password for the administrator account.
- **Verify New Password** Re-enter the new password for the administrator account.



**Note:** Password length is 8 characters maximum, passwords exceeding 8 characters will be truncated.

**Enable Read-Only Account** Click to enable the read-only account and configure the username and password to protect your device from unauthorized access. The default option is *disabled*.

- **Read-Only Username** Specifies the name of the system user.
- **Key button** Press this button in order to change the Read-only password.
  - **New Password** New password used for read-only administrator authentication should be specified.
  - **Show** Check this to display the read-only password characters you have typed.

**Change** Click to save changes to any of the fields on the *System* tab.

## Configuration Management

The device configuration is stored in plain text file (cfg file). Use the *Configuration Management* controls to backup, restore or update the system configuration file:

**Backup Configuration** Click **Download** to download the current system configuration file.

**Upload Configuration** Click **Browse** to navigate to and select the new configuration file or specify the full path to the configuration file location. Click **Upload** to use a previously downloaded configuration file to the system.

The settings of the new configuration will be visible in the *Main*, *Network*, *Services* and *System* tabs of the Web Management Interface.



**Note:** The new configuration is active after clicking **Apply** and the system reboot cycle is completed. The previous system configuration is deleted after you click **Apply**. It is highly recommended to backup the system configuration before uploading the new configuration.

## Device Maintenance

The controls in this section are dedicated for the device maintenance routines: rebooting, resetting, generating of the support information report.

**Firmware Version** Shows the current firmware version.

**Build Number** Displays the build number of the firmware version loaded.

**Update** Click to update the device with new firmware.

### • Firmware Upload

The device firmware update is compatible with all configuration settings. System configurations are preserved while the device is updated with a new firmware version.

- **Current Firmware** Displays the version of the AirOS firmware which is currently operating.
- **Firmware File** Click **Choose File** to locate new firmware file. Select the file and click **Open**. Once you've selected a new firmware file, click **Upload** to upload the new firmware to the device. Click **Close this window** to cancel the new firmware upload process.
- **Update** Click the *Update* button to proceed with the firmware upgrade routine (new firmware image should be uploaded into the system first). Please be patient, as the firmware upgrade routine can take 3-7 minutes. The airCam will be inaccessible until the firmware upgrade routine is completed.
- Do not switch off, do not reboot and do not disconnect the airCam from the power supply during the firmware upgrade process as these actions will damage the device!

- It is highly recommended that you back up the system configuration and the Support Info file before uploading the new configuration.
- **Close this window** At this point, closes the firmware upgrade window if activated. This action will not cancel the firmware upgrade process.

**Reboot** Click *Reboot* in order to initiate the full reboot cycle of the device. Reboot is the same as the hardware reboot which is similar to the power off - power on cycle. The system configuration is not modified after the reboot cycle completes. Any non-applied changes will be lost.

**Reset to Defaults** Use this to reset the airCam to the factory default settings. This option will reboot the airCam and all factory default settings will be restored. You may want to use the *Backup Configuration* option to download your current settings before selecting this option.

**Support Info** This will generate a support information file that the Ubiquiti support engineers can use when providing customer support. This file only needs be generated at their request.

## Appendix A: Specifications

airCam Specifications	
Dimensions	158 x 61.5 x 58.5 mm (without mounting arm) 264 x 61.5 x 58.5 mm (with mounting arm)
Weight	240 g (196 g without mounting arm)
Ports	(1) 10/100 Ethernet
Sensor	Progressive Scan RGB CMOS ¼"
Lens	4.0mm/ F1.5
Horizontal of View	47°
Ethernet Ports	Auto MDIX, autosensing 10/100 Mbps
Power LED	Orange
Link/Active LED	Green
Buttons	Factory Reset Button
Power Method	Passive Power over Ethernet (12-24V)
Power Supply	24V/0.5A PoE Adapter included
Maximum Power Consumption	2.4 Watts
Certifications	CE, FCC, IC
Mounting	Wall/Ceiling Adapter Kit included
Operating Temperature	-40 to 70° C (-40 to 158° F)
Operating Humidity	20 - 80% Noncondensing

Video	
Video Compression	H.264/MPEG-4/MJPEG
Resolution	1MP/HDTV 720p
Maximum Frame Rate	30 FPS
Image Setting	Brightness, Contrast, Sharpness, Saturation, 50Hz/60Hz

General	
Processor	ARM-based 32-bit RISC
Memory	128MB DDR2 SDRAM, 8MB Flash
Connector	RJ-45 10BASE-T/100BASE-TX PoE
Maximum Active Array Size	1280x800
View Angle	47° (H) 31° (V) 54° (D)

Network	
Security	Multiple user access levels with password protection, User access log
Supported Protocols	IPv4/v6, HTTP, UPnP, DNS, NTP, RTSP, DHCP, TCP, UDP, IGMP, RTCP, ICMP, ARP

## Appendix B: Safety Notices

---

1. Read, follow, and keep these instructions.
2. Heed all warnings.
3. Only use attachments/accessories specified by the manufacturer.



**WARNING:** Do not use this product in location that can be submerged by water.



**WARNING:** Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.

### Electrical Safety Information

1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed.
2. There are no operator serviceable parts inside this equipment. Service should be provided only by a qualified service technician.
3. This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet.
  - a. Do not substitute the power cord with one that is not the provided approved type. Never use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire.
  - b. The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.
  - c. Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.
  - d. Protective earthing is provided by Listed AC adapter. Building installation shall provide appropriate short-circuit backup protection.
  - e. Protective bonding must be installed in accordance with local national wiring rules and regulations.



## Appendix C: Warranty

### General Warranty

UBIQUITI NETWORKS, Inc (“UBIQUITI NETWORKS”) represents and warrants that the Products furnished hereunder shall be free from defects in material and workmanship for a period of one (1) year from the date of shipment by UBIQUITI NETWORKS under normal use and operation. UBIQUITI NETWORKS sole and exclusive obligation under the foregoing warranty shall be to repair or replace, at its option, any defective Product that fails during the warranty period. The expense of removal and reinstallation of any item is not included in this warranty.

The foregoing warranty is exclusive and in lieu of all other warranties, express or implied, including the implied warranties of merchantability and fitness for a particular purpose and any warranties arising from a course of dealing, usage or trade practice with respect to the products. Repair or replacement in the manner provided herein shall be the sole and exclusive remedy of Buyer for breach of warranty and shall constitute fulfillment of all liabilities of UBIQUITI NETWORKS with respect to the quality and performance of the Products. UBIQUITI NETWORKS reserves the right to inspect all defective Products (which must be returned by Buyer to UBIQUITI NETWORKS factory freight prepaid).

No Products will be accepted for replacement or repair without obtaining a Return Materials Authorization (RMA) number from UBIQUITI NETWORKS. Products returned without an RMA number will not be processed and will be returned to Buyer freight collect. UBIQUITI NETWORKS shall have no obligation to make repairs or replacement necessitated by catastrophe, fault, negligence, misuse, abuse, or accident by Buyer, Buyer’s customers or any other parties. The warranty period of any repaired or replaced. Product shall not extend beyond its original term.

### Warranty Conditions

The foregoing warranty shall apply only if:

- (I) The Product has not been subjected to misuse, neglect or unusual physical, electrical or electromagnetic stress, or some other type of accident.
- (II) No modification, alteration or addition has been made to the Product by persons other than UBIQUITI NETWORKS or UBIQUITI NETWORKS’ authorized representatives or otherwise approved by UBIQUITI NETWORKS.
- (III) The Product has been properly installed and used at all times in accordance, and in all material respects, with the applicable Product documentation.
- (IV) All Ethernet cabling runs use CAT5 (or above) shielded cabling.

### Disclaimer

UBIQUITI NETWORKS does not warrant that the operation of the products is error-free or that operation will be uninterrupted. In no event shall UBIQUITI NETWORKS be responsible for damages or claims of any nature or description relating to system performance, including coverage, buyer’s selection of products for buyer’s application and/or failure of products to meet government or regulatory requirements.

### Returns

In the unlikely event a defect occurs, please work through the dealer or distributor from which this product was purchased.

## Appendix D: Compliance Information

### Installer Compliance Responsibility

Devices must be professionally installed and it is the professional installer's responsibility to make sure the device is operated within local country regulatory requirements.

### FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operations of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### Industry Canada

This Class B digital apparatus complies with Canadian ICES-003. Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication.

**Class B device (Broadcasting Communication Device for Home Use):** This device obtained EMC registration mainly for home use (Class B) and may be used in all areas.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 Canada. Son fonctionnement est soumis aux deux conditions suivantes:

1. Cet appareil ne peut pas provoquer d'interférences et
2. Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement du dispositif.

Pour réduire le risque d'interférence aux autres utilisateurs, l'antenne type et son gain doivent être choisies de façon que l'équivalent puissance isotrope rayonnée équivalente (pire) n'est pas plus que cela autorisé pour une communication réussie.

### Class B Korea

**Class B device (Broadcasting Communication Device for Home Use):** This device obtained EMC registration mainly for home use (Class B) and may be used in all areas.

**A급 기기 (업무용 방송통신기기):** 이 기기는 업무용(A급)으로 전자파적합등록을 한 기기이오니 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

**B급 기기 (가정용 방송통신기기):** 이 기기는 가정용(B급)으로 전자파적합등록을 한 기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

### CE Marking

CE marking on this product represents the product is in compliance with all directives that are applicable to it.

#### Alert sign! Follows CE marking

Alert sign must be indicated if a restriction on use applied to the product and it must follow the CE marking.



#### NB-Identification number (if there is any)

Notified body number is indicated if it is involved in the conformity assessment procedure.



Please check the CE mark on the product label to find out which notified body was involved during assessment.

## RoHS/WEEE Compliance Statement



### English

European Directive 2002/96/EC requires that the equipment bearing this symbol on the product and/or its packaging must not be disposed of with unsorted municipal waste. The symbol indicates that this product should be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electric and electronic equipment via designated collection facilities appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about the disposal of your old equipment, please contact your local authorities, waste disposal service, or the shop where you purchased the product.

### Deutsch

Die Europäische Richtlinie 2002/96/EC verlangt, dass technische Ausrüstung, die direkt am Gerät und/oder an der Verpackung mit diesem Symbol versehen ist, nicht zusammen mit unsortiertem Gemeindeabfall entsorgt werden darf. Das Symbol weist darauf hin, dass das Produkt von regulärem Haushaltsmüll getrennt entsorgt werden sollte. Es liegt in Ihrer Verantwortung, dieses Gerät und andere elektrische und elektronische Geräte über die dafür zuständigen und von der Regierung oder örtlichen Behörden dazu bestimmten Sammelstellen zu entsorgen. Ordnungsgemäßes Entsorgen und Recyceln trägt dazu bei, potentielle negative Folgen für Umwelt und die menschliche Gesundheit zu vermeiden. Wenn Sie weitere Informationen zur Entsorgung Ihrer Altgeräte benötigen, wenden Sie sich bitte an die örtlichen Behörden oder städtischen Entsorgungsdienste oder an den Händler, bei dem Sie das Produkt erworben haben.

### Español

La Directiva 2002/96/CE de la UE exige que los equipos que lleven este símbolo en el propio aparato y/o en su embalaje no deben eliminarse junto con otros residuos urbanos no seleccionados. El símbolo indica que el producto en cuestión debe separarse de los residuos domésticos convencionales con vistas a su eliminación. Es responsabilidad suya desechar este y cualesquiera otros aparatos eléctricos y electrónicos a través de los puntos de recogida que ponen a su disposición el gobierno y las autoridades locales. Al desechar y reciclar correctamente estos aparatos estará contribuyendo a evitar posibles consecuencias negativas para el medio ambiente y la salud de las personas. Si desea obtener información más detallada sobre la eliminación segura de su aparato usado, consulte a las autoridades locales, al servicio de recogida y eliminación de residuos de su zona o pregunte en la tienda donde adquirió el producto.

### Français

La directive européenne 2002/96/CE exige que l'équipement sur lequel est apposé ce symbole sur le produit et/ou son emballage ne soit pas jeté avec les autres ordures ménagères. Ce symbole indique que le produit doit être éliminé dans un circuit distinct de celui pour les déchets des ménages. Il est de votre responsabilité de jeter ce matériel ainsi que tout autre matériel électrique ou électronique par les moyens de collecte indiqués par le gouvernement et les pouvoirs publics des collectivités territoriales. L'élimination et le recyclage en bonne et due forme ont pour but de lutter contre l'impact néfaste potentiel de ce type de produits sur l'environnement et la santé publique. Pour plus d'informations sur le mode d'élimination de votre ancien équipement, veuillez prendre contact avec les pouvoirs publics locaux, le service de traitement des déchets, ou l'endroit où vous avez acheté le produit.

### Italiano

La direttiva europea 2002/96/EC richiede che le apparecchiature contrassegnate con questo simbolo sul prodotto e/o sull'imballaggio non siano smaltite insieme ai rifiuti urbani non differenziati. Il simbolo indica che questo prodotto non deve essere smaltito insieme ai normali rifiuti domestici. È responsabilità del proprietario smaltire sia questi prodotti sia le altre apparecchiature elettriche ed elettroniche mediante le specifiche strutture di raccolta indicate dal governo o dagli enti pubblici locali. Il corretto smaltimento ed il riciclaggio aiuteranno a prevenire conseguenze potenzialmente negative per l'ambiente e per la salute dell'essere umano. Per ricevere informazioni più dettagliate circa lo smaltimento delle vecchie apparecchiature in Vostro possesso, Vi invitiamo a contattare gli enti pubblici di competenza, il servizio di smaltimento rifiuti o il negozio nel quale avete acquistato il prodotto.

# Appendix E: Declaration of Conformity

<b>Česky</b> [Czech]	UBIQUITI NETWORKS tímto prohlašuje, že tento UBIQUITI NETWORKS device, je ve shodě se základními požadavky a dále implemňuje všechny ustanovení směrnice 1999/5/ES.
<b>Dansk</b> [Danish]	Undertegnede UBIQUITI NETWORKS erklærer herved, at følgende udstyr UBIQUITI NETWORKS device, overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.
<b>Nederlands</b> [Dutch]	Hierbij verklaart UBIQUITI NETWORKS dat het toestel UBIQUITI NETWORKS device, in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG. Bij deze verklaart UBIQUITI NETWORKS dat deze UBIQUITI NETWORKS device, voldoet aan de essentiële eisen en aan de overige relevante bepalingen van Richtlijn 1999/5/EC.
<b>English</b>	Hereby, UBIQUITI NETWORKS, declares that this UBIQUITI NETWORKS device, is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
<b>Eesti</b> [Estonian]	Käesolevaga kinnitab UBIQUITI NETWORKS seadme UBIQUITI NETWORKS device, vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.
<b>Suomi</b> [Finnish]	UBIQUITI NETWORKS vakuuttaa täten että UBIQUITI NETWORKS device, tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.
<b>Français</b> [French]	Par la présente UBIQUITI NETWORKS déclare que l'appareil UBIQUITI NETWORKS, device est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE. Par la présente, UBIQUITI NETWORKS déclare que ce UBIQUITI NETWORKS device, est conforme aux exigences essentielles et aux autres dispositions de la directive 1999/5/CE qui lui sont applicables.
<b>Deutsch</b> [German]	Hiermit erklärt UBIQUITI NETWORKS, dass sich diese UBIQUITI NETWORKS device, in Übereinstimmung mit den grundlegenden Anforderungen und den anderen relevanten Vorschriften der Richtlinie 1999/5/EG befindet". (BMW) Hiermit erklärt UBIQUITI NETWORKS die Übereinstimmung des Gerätes UBIQUITI NETWORKS device, mit den grundlegenden Anforderungen und den anderen relevanten Festlegungen der Richtlinie 1999/5/EG. (Wien)
<b>Ελληνική</b> [Greek]	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ UBIQUITI NETWORKS ΔΗΛΩΝΕΙ ΟΤΙ UBIQUITI NETWORKS device, ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.
<b>Magyar</b> [Hungarian]	Alulírott, UBIQUITI NETWORKS nyilatkozom, hogy a UBIQUITI NETWORKS device, megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.
<b>Íslenska</b> [Icelandic]	Hér með lýsir UBIQUITI NETWORKS yfir við UBIQUITI NETWORKS device, er í samræmi við grunnkröfur og allar kröfur, sem gerar eru í tilskipun 1999/5/EC.
<b>Italiano</b> [Italian]	Con la presente UBIQUITI NETWORKS dichiara che questo UBIQUITI NETWORKS device, è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.
<b>Latviski</b> [Latvian]	Ar o UBIQUITI NETWORKS deklar, ka UBIQUITI NETWORKS device, atbilst Direktīvas 1999/5/EK prasībām un citiem ar to saistītiem noteikumiem.
<b>Lietuvi</b> [Lithuanian]	UBIQUITI NETWORKS deklaruoja, kad šis UBIQUITI NETWORKS įrenginys atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.
<b>Malti</b> [Maltese]	Hawnhekk, UBIQUITI NETWORKS, jiddikjara li dan UBIQUITI NETWORKS device, jikkonforma mal- ti ijjiet essenzjali u ma provvedimenti o rajn relevanti li hemm fid-Direttiva 1999/5/EC.
<b>Norsk</b> [Norwegian]	UBIQUITI NETWORKS erklærer herved at utstyret UBIQUITI NETWORKS device, er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

<b>Slovensky</b> [Slovak]	UBIQUITI NETWORKS týmto vyhlasuje, že UBIQUITI NETWORKS device, spĺňa základné požiadavky a v etky príslušné ustanovenia Smernice 1999/5/ES.
<b>Svenska</b> [Swedish]	Härmed intygar UBIQUITI NETWORKS att denna UBIQUITI NETWORKS device, står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.
<b>Español</b> [Spanish]	Por medio de la presente UBIQUITI NETWORKS declara que el UBIQUITI NETWORKS device, cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.
<b>Polski</b> [Polish]	Niniejszym, firma UBIQUITI NETWORKS oświadczam, że produkt serii UBIQUITI NETWORKS device, spełnia zasadnicze wymagania i inne istotne postanowienia Dyrektywy 1999/5/EC.
<b>Português</b> [Portuguese]	UBIQUITI NETWORKS declara que este UBIQUITI NETWORKS device, está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

## Appendix F: Contact Information

---

### Ubiquiti Networks Support

Ubiquiti Support Engineers are located in the U.S. and Europe and are dedicated to helping customers resolve software, hardware compatibility, or field issues as quickly as possible. We strive to respond to support inquiries within a 24 hour period.

Email: [support@ubnt.com](mailto:support@ubnt.com)

Phone: 408-942-1153 (9 a.m. - 5 p.m. PST)

### Online Resources

Wiki Page: [www.ubnt.com/wiki](http://www.ubnt.com/wiki)

Support Forum: [www.ubnt.com/forum](http://www.ubnt.com/forum)

Downloads: [www.ubnt.com/support/downloads](http://www.ubnt.com/support/downloads)



91 E. Tasman Drive  
San Jose, CA 95134  
[www.ubnt.com](http://www.ubnt.com)

© 2011 Ubiquiti Networks, Inc. All rights reserved.