



# EdgeSwitch'10 C Quick Start Guide

# Introduction

Thank you for purchasing the Ubiquiti Networks® EdgeSwitch® 10XP. This Quick Start Guide is designed to guide you through installation and also includes warranty terms.

## Package Contents



EdgeSwitch 10XP

1.1

Wall Mount Screws (Qty. 2)

Wall Mount Anchors (Qty. 2)





ଙ Ground Screw

Power Adapter (24V, 2.5A)

Power Cord

Cable Clip

# Installation Requirements

- For indoor applications, use Category 5 (or above) UTP cabling approved for indoor use.
- For outdoor applications, shielded Category 5 (or above) cabling should be used for all wired Ethernet connections and should be grounded through the AC ground of the power supply.

We recommend that you protect your networks from harmful outdoor environments and destructive ESD events with industrial-grade, shielded Ethernet cable from Ubiquiti Networks. For more details, visit: www.ubnt.com/toughcable



WARNING: To reduce the risk of fire or electric shock, do not expose the EdgeSwitch to rain or moisture.



Note: Although the cabling can be located outdoors, the EdgeSwitch itself should be housed inside a protective enclosure.

# Hardware Overview

## Front Panel Ports



Interface	Description
RJ45 1-8	RJ45 ports support 10/100/1000 Ethernet connections and 24V Passive Power over Ethernet (PoE) output.
SFP 9-10	Hot-swappable SFP ports support 1 Gbps connections. If you use a copper Ethernet module (example: UF-RJ45-1G), power off the EdgeSwitch before insertion; otherwise there may be a device reboot.

# Front Panel Button

Reset



Button	Description			
	To reset to factory defaults:			
	1. Disconnect power from the EdgeSwitch.			
Reset	<ol> <li>Reconnect power while holding the Reset button. The port LEDs will light up in sequential order (this takes approximately five seconds).</li> </ol>			
	3. When the port 1 LED flashes again, release the <b>Reset</b> button.			

# Front Panel LEDs

System

## System LED

State	Status			
Flashing White	Bootup in Progress			
White	Ready for Use Not Connected to Ubiquiti® Network Management System (UNMS <sup>™</sup> )			
Blue	Ready for Use Connected to UNMS			
Steady Blue with Occasional Flashing	Ready for Use Unable to Connect to UNMS			
Quickly Flashing Blue	Used to Locate a Device in UNMS			
Alternating Blue/White	Firmware Upgrade in Progress			

## RJ45 LEDs



LED	State	Status
PoE	Off	No Power over Ethernet
POE	Green	24V Power over Ethernet
	Off	No Link
	Amber	Link Established at 10/100 Mbps
Speed/ Link/	Amber Flashing	Link Activity at 10/100 Mbps
Activity	Green	Link Established at 1000 Mbps
	Green Flashing	Link Activity at 1000 Mbps

SFP LEDs

Link/Activity



LED	State	Status
	Off	No Link
Link/ Activity	Green	Link Established at 1 Gbps
Activity	y Green Flashing	Link Activity at 1 Gbps


# Back Panel

Power

Grounding Point

Interface	Description
Power	Connect the included <i>Power Adapter</i> to the <i>Power</i> port.
Grounding Point	Ground bonding point for an optional ground wire.

# Side Panel



# Hardware Installation

The EdgeSwitch can be placed on a horizontal surface, mounted on a wall, or mounted in a rack (brackets not included). The optional EdgeRouter<sup>™</sup> Rackmount Kit, model ER-RMKIT, is sold separately.


Follow the *Wall Mounting* instructions to mount the EdgeSwitch using the included screws and anchors.

- WARNING: FAILURE TO PROVIDE PROPER VENTILATION MAY CAUSE FIRE HAZARD. KEEP AT LEAST 20 MM OF CLEARANCE NEXT TO THE VENTILATION HOLES FOR ADEQUATE AIRFLOW.
- WARNING: The EdgeSwitch ES-10XP must not be stacked. Do not place it on top of another switch. Do not place anything on top of the ES-10XP.

## Wall Mounting

To mount the EdgeSwitch on a wall, you will need a drill, a 6 mm drill bit, and a Phillips screwdriver.

- 1. Use a 6 mm drill bit to drill two holes 148 mm apart.
- Insert the Wall Mount Anchors into the holes. Use a Phillips screwdriver to secure a Wall Mount Screw to each anchor. Leave a clearance of approximately 3 mm between each screw head and its anchor.





Note: You can also mount the EdgeSwitch in a vertical orientation.


 Position the EdgeSwitch with the Ethernet ports facing down. Place the wall-mount slots of the EdgeSwitch over the screw heads on the wall. Then slide the EdgeSwitch down to lock it into place.



# Grounding the EdgeSwitch (Recommended)

The EdgeSwitch is grounded through the *Power Adapter*; however, you can add optional ESD grounding for enhanced ESD protection.

1. Attach the *Ground Screw* to secure a ground wire (not included) to the *Grounding Point*.



- Optional: To secure the Power Adapter cord, insert it into the Cable Clip and secure the Cable Clip using the Ground Screw.
- 3. Secure the other end of the ground wire to a grounding block.

# **Connecting Power**

1. Connect the Power Adapter to the Power port.



2. Connect the Power Cord to the Power Adapter.



3. Connect the other end of the Power Cord to a power outlet.



# **Connecting Ethernet**

1. Connect an Ethernet cable from your DHCP server or LAN system to any port on the EdgeSwitch.



Connect your computer or host system and other devices to the other ports on the EdgeSwitch.



# **Using SFP Ports**

To use an SFP port:

- 1. Remove the protective plug covering the SFP port.
- 2. Plug a compatible fiber module into the SFP port.



Connect the fiber optic cable to the fiber module. Then connect the other end of the cable to another fiber device.



For information about compatible fiber SFP modules, visit: ubnt.link/SFP\_DAC\_Compatibility

# Accessing the Configuration Interface

The EdgeSwitch is set to DHCP by default, so it will try to automatically obtain an IP address. If that fails, then it will use the default fallback IP address, 192.168.1.20. Proceed to the appropriate section, DHCP or "*Fallback IP Address*":

## DHCP

Use one of the following methods:

- Set up the DHCP server to provide a specific IP address to the EdgeSwitch based on its MAC address (on the label).
- Let the EdgeSwitch obtain an IP address and then check the DHCP server to see which IP address was assigned.

To log in, follow these steps:

- Launch your web browser. Type the appropriate IP address in the address field. Press enter (PC) or return (Mac).
- The login screen will appear. Enter ubnt in the Username and Password fields. Click Sign In.


EdgeSwitch	
1220	
By signing in to the first decision are spins in he because by the	

The EdgeSwitch Configuration Interface will appear.

Customize additional settings as needed. For 24V Passive PoE configuration, refer to "<u>Configuring PoE Settings</u>". For more information, refer to the EdgeSwitch documentation, which is available at www.ubnt.com/download/edgemax

## Fallback IP Address

- 1. Ensure that your computer (or other host system) is connected to the EdgeSwitch.
- Configure the Ethernet adapter on your host system with a static IP address on the 192.168.1.x subnet.
- Launch your web browser. Type the appropriate IP address in the address field (192.168.1.20 is the default fallback IP address). Press enter (PC) or return (Mac).



 The login screen will appear. Enter ubnt in the Username and Password fields. Click Sign In. (When you sign in, you agree to accept the Ubiquiti License Agreement.)

EdgeSwitch	
_	

 The EdgeSwitch Configuration Interface will appear. Click the System Settings tab.

-	-	- maile	والتج ا				
		10.5					
Inter		where a					-
-		10,000					
-		the second					
-	-						
-	-				22.		
1	-	-	-	1.000	Hay Them		
- 1					1111		
	-	-			-	+	
	111	-			***		(0)
	-				84	+ :	(0.)
+	-	-			tea.	+11	
	-				**	+	-0.1
	-	-			111	* * * * *	
	-	-			++		10.1
	-	-			14		

6. Change the IP Address to a unique IP address. Click Apply.

howkey	B00-000		
farinese factors	10.000 		•
Nongeren #			
*	the second se		
Annual Annua	-		
An and a set of the se			•
And Andrewson Andrewson	111	440	



be cut off, and you will need to reconnect to the Note: If you change the IP settings, the session will EdgeSwitch using the new IP address.

The EdgeSwitch Configuration Interface will appear. Customize additional settings as needed. For 24V Passive PoE configuration, refer to "Configuring PoE Settings". For more information, refer to the EdgeSwitch documentation, which is available at www.ubnt.com/download/edgemax

# **UNMS Management**

You can manage your device using UNMS, which lets you configure, monitor, upgrade, and back up your devices using a single application. Get started at www.unms.com

# **Configuring PoE Settings**

The PoE setting for ports 1-8 is set to Off by default.



WARNING: Before activating PoE, ensure that the connected device supports passive PoE and the supplied voltage.

1. On the *Dashboard* tab, click the **PoE** setting of the Ethernet port you want to configure. Then select **24V**.

11.00		and the second	-	and and a second second					100
				_					
		105							
	÷.								
inter-	100	abover.			**				
11000		1120-0030							
-		whether .							
-	ana i								
	-				100		22.	-	
1			-	india.	-	Link	1 1 1 1 1 1	-	
	-						84	40	
							44	*	0.1
4	-	-							
	-	-					**		10.4
	-						84		
	-						**		
	-	144					**	\$	.0.4
	-	10							
	-	-					**	•	-0.4

2. The Ethernet port's PoE LED will confirm the PoE setting.



# Specifications

	ES-10XP
Dimensions	207 x 31.1 x 90 mm (8.15 x 1.22 x 3.54")
Weight	500 g (1.10 lb)
Total Non-Blocking Throughput	10 Gbps
Switching Capacity	20 Gbps
Forwarding Rate	14.88 Mpps
Max. Power Consumption (Excluding PoE Output)	8W
Power Method	24VDC, 2.5A
Supported Voltage Range	9 - 30VDC, 5A
Power Supply	24VDC, 2.5A Power Adapter (Included)
LEDs System RJ45 Data Ports SFP Data Ports	Status PoE, Link/Speed/Activity Link/Activity
Networking Interfaces	(8) 10/100/1000 Mbps RJ45 Ports (2) 1 Gbps SFP Ports
Management Interface	Ethernet In-Band
Certifications	CE, FCC, IC
ESD/EMP Protection	Air: ± 24 kV, Contact: ± 24 kV
Operating Temperature	-10 to 50° C (14 to 122° F)
Operating Humidity	5 to 95% Noncondensing
Shock and Vibration	ETSI300-019-1.4 Standard

PoE	
PoE Interface	(8) 24VDC Passive PoE (Pins 4, 5+; 7, 8-)
Max. Passive PoE Wattage per Port	15W
24V Passive PoE Voltage Range	24V

# Safety Notices

- 1. Read, follow, and keep these instructions.
- 2 Heed all warnings.
- 3. Only use attachments/accessories specified by the manufacturer.



WARNING: Failure to provide proper ventilation may cause fire hazard. Keep at least 20 mm of clearance next to the ventilation holes for adequate airflow.



WARNING: To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.



WARNING: Do not use this product in location that can be submerged by water.



WARNING: Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.

# **Electrical Safety Information**

- Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed.
- 2. There are no operator serviceable parts inside this equipment. Service should be provided only by a gualified service technician.
- This equipment is provided with a detachable power cord which has 3 an integral safety ground wire intended for connection to a grounded safety outlet.
  - a. Do not substitute the power cord with one that is not the provided approved type. Never use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire.
  - b. The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.
  - c. Contact a gualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.
  - d. Protective earthing is provided by Listed AC adapter. Building installation shall provide appropriate short-circuit backup protection.
  - e. Protective bonding must be installed in accordance with local national wiring rules and regulations.

# **Limited Warranty**

#### www.ubnt.com/support/warranty/

The limited warranty requires the use of arbitration to resolve disputes on an individual basis, and, where applicable, specify arbitration instead of jury trials or class actions.

# Compliance

## FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operations of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference.

## **ISED** Canada

## CAN ICES-3(A)/NMB-3(A)

This Class A digital apparatus complies with Canadian CAN ICES-003.

## CAN ICES-3(A)/NMB-3(A)

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

## Australia and New Zealand



Warning: This equipment is compliant with Class A of CISPR 32. In a residential environment this equipment may cause radio interference.

## **CE Marking**

CE marking on this product represents the product is in compliance with all directives that are applicable to it.

CE

## **RoHS/WEEE Compliance Statement**



## English

European Directive 2012/19/EU requires that the equipment bearing this symbol on the product and/or its packaging must not be disposed of with unsorted municipal waste. The symbol indicates that this product should be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electric and electronic equipment via designated collection facilities appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about the disposal of your old equipment, please contact your local authorities, waste disposal service, or the shop where you purchased the product.

## Deutsch

Die Europäische Richtlinie 2012/19/EU verlangt, dass technische Ausrüstung, die direkt am Gerät und/oder an der Verpackung mit diesem Symbol versehen ist, nicht zusammen mit unsortiertem Gemeindeabfall entsorgt werden darf. Das Symbol weist darauf hin, dass das Produkt von regulärem Haushaltmüll getrennt entsorgt werden sollte. Es liegt in Ihrer Verantwortung, dieses Gerät und andere elektrische und elektronische Geräte über die dafür zuständigen und von der Regierung oder örtlichen Behörden dazu bestimmten Sammelstellen zu entsorgen. Ordnungsgemäßes Entsorgen und Recyceln trägt dazu bei, potentielle negative Folgen für Umwelt und die menschliche Gesundheit zu vermeiden. Wenn Sie weitere Informationen zur Entsorgung Ihrer Altgeräte benötigen, wenden Sie sich Sitte an die örtlichen Behörden oder städtischen Entsorgungsdienste oder an den Händler, bei dem Sie das Produkt erworben haben.

## Español

La Directiva 2012/19/UE exige que los equipos que lleven este símbolo en el propio aparato y/o en su embalaje no deben eliminarse junto con otros residuos urbanos no seleccionados. El símbolo indica que el producto en cuestión debe separarse de los residuos domésticos convencionales con vistas as ue leiminación. Es responsabilidad suya desechar este y cualesquiera otros aparatos eléctricos y electrónicos a través de los puntos de recogida que ponen a su disposición el gobierno y las autoridades locales. Al desechar y reciciar correctamente estos aparatos estará contribuyendo a evitar posibles consecuencias negativas para el medio ambiente y la salud de las personas. Si desea obtener información más detallada sobre la eliminación segura de su aparato usado, consulte a las autoridades locales, al servicio de recogida y eliminación de residuos de su zona o pregunte en la tienda donde adquirió el producto.

## Français

La directive européenne 2012/19/UE exige que l'équipement sur lequel est apposé ce symbole sur le produit et/ou son emballage ne soit pas jeté avec les autres ordures ménagères. Ce symbole indique que le produit doit être éliminé dans un circuit distinct de celui pour les dèchets des ménages. Il est de votre responsabilité de jetre ce matériei al ains que tout autre matériel électrique ou électronique par les moyens de collecte indiqués par le gouvernement et les pouvoirs publics des collectivités territoriales. L'élimination et le recyclage en bonne et due forme ont pour but de lutter contre l'impact néfaste potentiel de ce type de produits sur l'environnement et la santé publique. Pour plus d'informations sur le mode d'élimination de votre ancien équipement, veuillez prendre contact avec les pouvoirs publics locaux, le service de traitement des dèchets, ou l'endroit où vous avez achet le produit.

## Italiano

La direttiva europea 2012/19/UE richiede che le apparecchiature contrassegnate con questo simbolo sul prodotto e/o sull'imballaggio non siano smalitte insieme ai rifiuti urbani non differenziati. Il simbolo indica che questo prodotto non deve essere smalitto insieme ai normali rifiuti domestici. E responsabilità del proprietario smaltire sia questi prodotti sia le altre apparecchiature elettriche ed elettroniche mediante le specifiche strutture di raccolta indicate dal governo o dagli enti pubblici locali. Il corretto smaltimento edi li riciclaggio aiuteranno a prevenire conseguenze potenzialmente negative per l'ambiente e per la salute dell'essere umano. Per ricevere informazioni più dettagliate circa lo smaltimento delle vecchie apparecchiature in Vostro possesso. Vi invitiamo a contattare gli enti pubblici di competenza, il servizio di smaltimento rifiuti o il negozio nel quale avete acquisatto il prodotto.

# **Declaration of Conformity**

български (Bulgarian) С настоящото UBIQUITI NETWORKS декларира, че това устройство ES-10XP в в съответствие със съществените изисквания и други приложими разпоредби на Директиви 2014/30/EC, 2014/35/EC, Цялостният текст на EC декларацията за съответствие може да се намери на следни интернет адрес: www.ubnt.com/compliance

Hrvatski (Croatian) UBIQUITI NETWORKS ovim putem izjavljuje da je ovaj uređaj ES-10XP sukladan osnovnim zahtjevima i ostalim bitnim odredbama Direktiva 2014/30/EU, 2014/35/EU. Cjeloviti tekst EU izjave o sukladnosti dostupan je na sljedećoj internetskoj adresi: www.ubnt.com/compliance

Čeština [Czech] UBIQUITI NETWORKS tímto prohlašuje, že toto ES-10XP zařízení, je ve shodé se základními požadavky a dalšími příslušnými ustanoveními směrnic 2014/30/EU, 2014/35/EU. Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese: www.ubrt.com/compliance

Dansk [Danish] Hermed, UBIQUITI NETWORKS, erklærer at denne ES-10XP enhed, er i overensstemmelse med de væsentlige krav og øvrige relevante krav i direktiver 2014/30/EU, 2014/35/EU. EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse www.ubnt.com/compliance

Nederlands (Dutch) Hierbij verklaart UBIQUITI NETWORKS, dat deze ES-10XP apparaat, in owereenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijnen 2014/30/EU, 2014/35/EU. De volledige tekst van de EU-conformiteitsverklaring kan worden genadpleegd op het volgende internetadres: www.ubnt.com/compliance

English Hereby, UBIQUITI NETWORKS, declares that this ES-10XP device, is in compliance with the essential requirements and other relevant provisions of Directives 2014/30/EU, 2014/35/EU. The full text of the EU declaration of conformity is available at the following internet address: www.ubrt.com/compliance

Eesti keel [Estonian] Käesolevaga UBIQUITI NETWORKS kinnitab, et antud ES-10XP seade, on vastavus olulistele nõuetele ja teistele asjakohastele sätetele direktiivide 2014/30/EL, 2014/35/EL. ELi vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetiaadressil: www.ubrt.com/compliance

Suomi [Finnish] Täten UBIQUITI NETWORKS vakuuttaa, että tämä ES-10XP laite, on yhdenmukainen olennaisten vaatimusten ja muiden sitä koskevien direktiivien 2014/30/EU, 2014/35/EU. EU-vaatimustenmukaisuusvakuutuksen täysimittainen teksisti on saatavilla seuraavassa internetosoittessa: www.ubnt.com/compliance

Français [French] Par la présente UBIQUITI NETWORKS déclare que l'appareil ES-10XP, est conforme aux exigences essentielles et aux autres dispositions pertinentes des directives 2014/30/UE, 2014/35/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: www.ubnt.com/compliance

Deutsch [German] Hiermit erklärt UBRUHTI NETWORKS, dass sich dieses ES-10XP Gerät, in Übereinstimmung mit den grundlegenden Anforderungen und den anderen relevanten Vorschriften der Richtlinien 2014/30/EU, 2014/35/EU befindet. Der vollständige Text der EU-Konformitätsreklärung ist unter der folgenden Internetadresse verfügbar: www.ubt.com/compliance

Ελληνικά (Greek) Δια του παρόντος, UBIQUITI NETWORKS, δηλώνει ότι αυτή η συσκευή ES-102% είναι σε συμμόρφωση με τις βασικές απατήσεις και τις λοιπές σχετικές διατάξεις των οδηγιών 2014/30/EE, 2014/35/EE. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: www.ubnt.com/compliance

Magyar [Hungarian] Ezennel UBIQUITI NETWORKS kijelenti, hogy ez a ES-10XP készülék megfelel az alapvető követelményeknek és más vonatkozó 2014/30/EU, 2014/35/EU irányelvek rendelkezéseit. Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internetes címen: www.ubnt.com/compliance

(slenska (icelandic) Hér, UBiQUITI NETWORKS, því yfir að þetta ES-10XP tæki er í samræmi við grunnkröfur og önnur viðeigandi ákvæði tilskipana 2014/30/ESB, 2014/35/ESB. Fullur texti ESB samræmisyfirlýsing er að finna á eftirfaranti netfangi: www.ubnt.com/compliance Italiano (Italian) Con la presente, UBIQUITI NETWORKS, dichiara che questo dispositivo ES-10XP, è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti delle direttive 2014/30/UE, 2014/35/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: www.ubnt.com/compliance

Latviešu valoda [Latvian]. Ar šo, UBIQUITI NETWORKS, deklarė, ka ES-10XP ierice, ir saskaņā ar būtiskajām prasībām un citiem attiecīgiem noteikumiem Direktīvās 2014/30/ES, 2014/35/ES. Pilns ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē: **www.ubnt.com/compliance** 

Lietuvių kalba [Lithuanian] UBIQUITI NETWORKS deklaruoja, kad šis ES-10XP įrenginys atitinka esminius reikalavimus ir kitas 2014/30/ES, 2014/35/ES Direktyvų nuostatas. Visas ES atitiklies deklaracijos tekstas prieinamas šiuo interneto adresu: **www.ubnt.com/compliance** 

Malti (Maltese) Hawnhekk, UBIQUITI NETWORKS, tiddikjara li dan il-mezz ES-10XP huwa konformi mar-rekwiżti essenzjali u dispożizzjonijijet rilevanti ohrajn ta 'Direttivi 2014/30/UE, 2014/35/UE. Id-dikjarazzjoni tal-konformita tista' tigi kkonsultata minn www.ubnt.com/compliance

Norsk (Norwegian) Herved UBIQUITI NETWORKS, erklærer at denne ES-10XP enheten, er i samsvar med de grunnleggende kravene og andre relevante bestemmelser i direktivene 2014/30/EU, 2014/35/EU. Den fulle teksten til EU-samsvarserklæringen er tilgjengelig på følgende internettadresse: www.ubnt.com/compliance

Polski (Polish) Niniejszym, Ubiquiti Networks, oświadcza, że urządzenie ES-10XP, jest zgodny z zasadniczymi wymaganiami oraz pozostałymi stosownymi postanowieniami Dyrektyw 2014/30/UE, 2014/35/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: www.ubnt.com/compliance

Português [Portuguese] UBIQUITI NETWORKS declara que este dispositivo ES-10XP, está conforme com os requisitos essenciais e outras disposições das Directivas 2014/30/UE, 2014/35/UE. O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: www.ubnt.com/compliance

Romànă [Romanian] Prin prezenta, UBIQUITI NETWORKS declară că acest dispozitiv ES-10XP este în conformitate cu cerințele esențiale și alte prevederi relevante ale Directivelor 2014/30/UE, 2014/35/UE. Textul integral al declarației UE de conformitate este disponibil la următoarea adresă internet **uww.ubnt.com/compliance** 

Slovenčina (Slovak) Týmto UBIQUITI NETWORKS, prehlasuje, že toto ES-10XP zariadenie, je v súlade so základnými požiadavkami a ďalšími relevantnými ustanoveniami smernice 2014/30/EÚ, 2014/35/EÚ. Úplné EÚ vyhlásenie o zhode je k dispozícii na tejto internetovej adrese: www.ubnt.com/compliance

Slovenščina [Slovenian] Družba UBIQUITI NETWORKS izjavlja, da je naprava ES-10XP v skladu z obveznimi zahtevami in drugimi ustreznimi določbami direktiv 2014/30/EU in 2014/35/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: www.ubrt.com/compliance

Español [Spanish] Por medio de la presente UBIQUITI NETWORKS declara que este dispositivo ES-10XP, cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de las Directivas 2014/30/UE, 2014/35/UE. El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: www.ubnt.com/compliance

Svenska [Swedish] Härmed UBIQUITI NETWORKS, intygar att denna ES-10XP enhet är i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiven 2014/30/EU, 2014/35/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: www.ubnt.com/compliance

# **Online Resources**

Support help.ubnt.com Community community.ubnt.com Downloads downloads.ubnt.com



www.ubnt.com

Ubiquiti Networks, Inc. 685 Third Avenue, 27th Floor New York, NY 10017 USA

©2018-2019 Ubiquiti Networks, Inc. All rights reserved. Ubiquiti, Ubiquiti Networks, the Ubiquiti Upog, the Ubiquiti beam logo, EdgeMAX, EdgeOS, EdgeRouter, EdgeSwitch, TOUGHCable, and UNNS are trademarks or registreed trademarks of Ubiquiti Networks, Inc. in the United States and in other countries. All other trademarks are the property of their respective owners.

JL010919